



For The ON-THE-GO Pet™

INSTRUCTION MANUAL

SPORT Pet Stroller

PG8030



To see our full line of products, visit us online at: www.petgearinc.com

CUSTOMER SERVICE HELP DESK

customerservice@petgearinc.com

Toll-Free 877-752-9123 - Eastern Standard Time 8am-3pm, Monday through Friday

⚠ WARNING!

- For pets only.
- Do not carry additional bags, goods, or accessories in or on stroller except as recommended in the manufacturer's instructions.
- Recommended use of an approved safety restraint correctly fitted and adjusted.
- Do not leave pet unsupervised in stroller.
- Before making adjustments to stroller ensure that pet's body is clear of any moving parts.
- This stroller is designed for one pet only.
- Do not hang bags from handles as this may cause the product to become unstable.
- Do not use on escalator or stairs; fold stroller and carry.
- Put on brake whenever you park the stroller.
- Ensure stroller is completely erected and check that all locks are engaged before placing pet in stroller.
- Do not overload as stroller may become unstable; maximum weight of pet using this stroller should not exceed 20 lbs.
- Any goods carried in the basket not to exceed 6 lbs.
- Do not use near an open or exposed flame.

**For Pets
Up To
20 lbs**


WHEEL MAINTENANCE

- To clean and lubricate front and rear wheels, push out locking lever under wheel housing to release rear wheel.
- To ensure ease of maneuverability and to minimize wear and tear, keep all moving parts clean and lubricated with WD40® or light machine oil.
- Push wheel sets back on until they click and lock in position; pull on wheel housings to ensure they are secure.
- Push stroller back and forth and rotate swivels around to work in lubricant.
- Clean the rear wheel assembly and the rest of the frame with warm, soapy water; clean off with warm water and dry thoroughly.


NOTE: Do not lubricate brake components.

PARTS LIST


Check that you have all the parts shown BEFORE assembling your product.
If any parts are missing, call Customer Service. No tools required.



Stroller Frame



Front Wheel Assembly (2)



Rear Wheels (2)



Rear Axle Assemblies



Washer (2)




Cotter Pin (2)



Hub Cap (2)

ASSEMBLY INSTRUCTIONS

To Open Stroller



Step 1. Release locking latch.




Step 2. Unfold as shown. Make sure both locks snap into place.

To Assemble Front Wheels

Step 1. Turn stroller over as shown.

Step 2. Push wheel assembly onto stroller leg until it snaps into place.

Step 3. Repeat for other wheel. Tug firmly on each wheel assembly to be sure wheels are securely in place.



Note Direction of Arrow

NOTE: To remove, squeeze tab and pull wheel off.



ASSEMBLY INSTRUCTIONS

To Assemble Rear Wheels

Step 1. Remove and discard protective sleeve from ends of rear axle assembly and rear leg tubes.

Step 2. Position rear axle assemblies onto rear leg tubes at the same time.

Step 3. Slide wheel onto axle.

Step 4. Slide washer onto axle.

Step 5. Fit straight part of cotter pin through hole on axle.

Step 6. Line up each of the tabs in the hub cap with the slots in the wheel. Snap hub cap into place. Fit cover to collet by firmly pressing the cover into place.

Step 7. Repeat for other side.



INSTRUCTIONS FOR USE

Applying the Brakes

Step 1. Push levers on both rear wheels down to lock.

Step 2. Pull levers up to lock.

WARNING: Never leave your stroller parked without applying brakes.



Folding the Stroller

Step 1. Before folding the stroller, lock the brakes and close the canopy.

Step 2. Standing behind the stroller, pull up on both side latches.



Step 3. Fold as shown.



NOTE: Fold stroller so wheels straddle frame. DO NOT allow wheels to press against frame as this may damage tires.

Step 4. Engage locking latch.



FEATURES

- Protective pet compartment.
- 600 denier waterproof material.
- Easy-fold mechanism.
- Front entry.
- Removable waterproof tray.
- Storage basket.
- Front wheels swivel.
- Rear safety brakes.
- Front shock absorbers.
- Maximum ventilation.
- Top window/viewing area.
- Bug-proof mesh.
- Interior dimensions:
22"L x 11"W x 16"H (55cm x 28cm x 40cm).

LOOKING AFTER YOUR STROLLER

- Always store product in a clean, dry place.
- Not recommended for use on the beach.
- Do not put heavy items on top of the stroller.
- Clean frame by wiping with a lightly oiled cloth.
- Do not use detergent or abrasives. Spot clean fabric with dry cleaning fluid or mild soap and warm water.
- To ensure easy maneuverability and to minimize wear and tear, (especially wheels, axles, and swivels), keep all moving parts clean and lubricated with WD40® or light machine oil.
- NOTE: Do not lubricate brake components or swivel locks.
- Regularly check stroller for loose parts. These should be tightened or replaced.

For Pets Only. Not intended to be used as a restraining device for aggressive or dangerous animals that dig, chew or paw aggressively. Do not leave your pet unattended for long periods of time. Pet Gear is not liable for any damage caused by aggressive, destructive, immature or untrained animals.



**PO Box 99
West Rutland, VT 05777
877-752-9123
www.petgearinc.com**