

K&H Manufacturing
Lectro-Soft
Heated Pet Bed

Thank you for purchasing K & H Manufacturing's Lectro-Soft™ heated pet bed. When used correctly, your Lectro-Soft™ should provide years of hassle free warmth for your pet. Your Lectro-Soft™ is intended for use indoors and outdoors in a doghouse or shelter. The unique Lectro-Soft™ heating system is designed to become warm when lied upon by your pet. Lectro-Soft™ is designed for use with animals only.

WARNING: This is an electrical product. Read all directions and precautions carefully before operating. Failure to properly follow all directions and instructions may lead to electrical shock or fire which could cause serious bodily injury.

For household use Only
Important safeguards

When using electrical appliances, basic safety precautions should always be followed including the following:

- 1. Read all instructions.**
- To protect against electrical hazards, **DO NOT** immerse cord, plug, or appliance in water or other liquid.
- Close supervision is necessary** when used by or near children.
- ALWAYS** unplug from outlet when not in use.
- DO NOT** operate any electrical appliance with a damaged cord or plug, or if the appliance malfunctions or has been damaged in any matter. **RETURN** all malfunctioning appliances to the factory for examination.
- DO NOT** use appliance for other than its intended use.
- DO NOT PUNCTURE PAD FOR ANY REASON.**
- For use with 110-120 volt AC **ONLY**.
- DO NOT** cover your Lectro-Soft™ with blankets or materials other than a fleece K&H Lectro-Soft cover™. Other coverings may not allow heat to radiate properly and could cause pad failure.
- 10.** When placing the pad in an enclosed area such as a doghouse, be sure pad covers no more than half of the floorspace so your pet has the option of sleeping on or off the Lectro-Soft™ heated pet bed.

INSTRUCTIONS

1. Place directly on a hard, flat surface in the home or inside a doghouse or kennel. Area chosen should be a sheltered area out of direct rain or snow.
2. Pull out the air valve on the bottom side of the bed. Plug into 110-120 volt AC outlet while the air valve is still released. Allow 15 to 30 minutes for the Lectro-Soft™ to begin to warm and fully expand. The unit will feel slightly warm to the touch. After desired expansion, push down on the center of the bed to remove a little air. Then push the air plug in to seal the bed. This will ensure against “ballooning” when your pet is enjoying the bed. The built in thermostat will automatically regulate the temperature.
3. After initial warm-up, your Lectro-Soft™ will feel cooler to the touch. This is the intension for energy efficiency. When your pet lies upon the bed, it will warm to a cozy, pet pleasing temperature even in the coldest of weather.
4. Testing your Lectro-Soft™ bed. Place a blanket, pillow or other insulating object over part of your Lectro-Soft™ bed. After a few minutes, place your hand under the insulating object to experience the warmth your pet will enjoy.
5. Cleaning. Your Lectro-Soft™ bed may be wiped down with a damp cloth when unplugged. The unit may be plugged back in for use when thoroughly dry..
6. To store your Lectro-Soft™ bed, unplug, clean, and store pad when not in use.

Limited 1 year warranty

K & H manufacturing warrants to the original consumer, that this product will be free of defects and workmanship for a period of one year from the date of purchase. The manufacturers liability here under is limited to replacement of the product. This warranty is void if the product has been damaged by accident, unreasonable use, neglect, tampering, or other causes not arising from defects in material or workmanship.

To exercise your warranty: If, during the warranty period, your product malfunctions, return it to the place of purchase with your **original purchase receipt**. If this cannot be done, return the product, postage prepaid, to K & H Manufacturing, with **dated proof of purchase or original dated receipt**. All returns to manufacturer must be accompanied by a return authorization number, obtained by calling (719)591-6950. Please include a note explaining the problem when returning the product.